

Thermodyne

Congratulations on the purchase of your new ABS Plastic Emblems from Watt's Truck Center! Your new emblem has been laser scanned and 3D molded from original OEM samples and constructed with high quality automotive plastic and covered with a show quality chrome finish in order to provide you with years of trouble free enjoyment!

Be sure to follow these general guidelines for easy installation...

1. Test fit to make sure the new emblem fits the desired area and covers any existing mounting holes. Use painter's tape to create mounting guide lines if needed.
2. Prep the mounting area to remove any rust, scaling, debris, etc...the mounting surface must be clean and flat. Make sure old mounting holes are flat and have no sharp, raised edges.
3. Clean the mounting area with a mild, oil free, paint safe cleaner to remove any dirt, grease, oil, wax and fingerprints. Mild alcohol prep pads work nicely but make sure your paint is cured first!
4. Peel the protective paper off of the emblem's pressure sensitive 3M Automotive adhesive backing and slowly place the emblem into position on the mounting area while taking care to follow your guide lines and/or measurements. Try to apply the emblem in a flat trajectory but it is useful to begin on one edge and work toward the opposite side.
5. The pressure sensitive 3M tape is extremely strong but it requires warm temperatures for installation. Only install in a climate controlled building or warm, sunny outside temperatures.

Thank you for your purchase! If you have any questions or concerns, call us at: 724-668-2201 or 1-88-304-6227 or email at: parts@wattstruck.com

